

Actuator Model Modulating Service	Power Source	Command Signal				Mounting Kit	Positioner			Feedback Pot	Feedback Transmitter	
		0-5V	0-10V	1-5V	4-20mA		Proportional	Log Rate	Digital High Resolution		0-5V / 0-10V	4-20mA
EPI-Lite	120 VAC	X	X	X	X	MKT-143	AMC-103			POT-102	XMA-106	XMA-105
EPI-3	120 VAC	X	X	X	X	MKT-110	AMC-103			POT-102	XMA-106	XMA-105
	220 VAC	X	X	X	X	MKT-110	AMC-103A			POT-102	XMA-106	XMA-105
	12 VDC				X	MKT-110	DMC-101			POT-102	**	XMA-105
	24 VDC				X	MKT-110	DMC-101			POT-102	**	XMA-105
EPI-6 EPI-13	120 VAC	**	X	X*	X*	MKT-106†	AMC-101A	LRC-101A		POT-102	XMA-106	XMA-105
	120 VAC	X	X	X*	X*	MKT-106			DHC-100	POT-102	OTX-100 or OTR-100	
	220 VAC	**	X	X*	X*	MKT-106†	AMC-101C	LRC-101B		POT-102	XMA-106	XMA-105
	220 VAC	X	X	X*	X*	MKT-106			DHC-100A	POT-102	OTX-100 or OTR-100	
	12 VDC											
EPI-36	24 VDC	X	X	X*	X*	MKT-106	DMC-100A w/ SLR-101			POT-102	**	XMA-105
	120 VAC	**	X	X*	X*	MKT-106†	AMC-101A	LRC-101A		POT-102	XMA-106	XMA-105
	120 VAC	X	X	X*	X*	MKT-106			DHC-100	POT-102	OTX-100 or OTR-100	
	220 VAC	**	X	X*	X*	MKT-106†	AMC-101C	LRC-101B		POT-102	XMA-106	XMA-105
	220 VAC	X	X	X*	X*	MKT-106			DHC-100A	POT-102	OTX-100 or OTR-100	
	12 VDC											
EPI-51 EPI-91 EPI-151	24 VDC	X	X	X*	X*	MKT-106	DMC-100A w/ SLR-100			POT-102	**	XMA-105
	120 VAC	**	X	X*	X*	MKT-106†	AMC-101A	LRC-101A		POT-102	XMA-106	XMA-105
	120 VAC	X	X	X*	X*	MKT-106			DHC-100	POT-102	OTX-100 or OTR-100	
	220 VAC	**	X	X*	X*	MKT-106†	AMC-101C	LRC-101B		POT-102	XMA-106	XMA-105
220 VAC	X	X	X*	X*	MKT-106			DHC-100A	POT-102	OTX-100 or OTR-100		

* Positioner can be set to open, close, or remain in its last position upon a loss of command signal.

** Call factory for more information.

† Use MKT-136 to wire to Tyco drawings BW-1301 and BW-1302.

Actuator Model Open/Close Service	Power Source	Control Signals	Mounting Kit	Controller	*Feedback Pot	Feedback Transmitter		Special Features
						0-5V / 0-10V	4-20mA	
EPI-6 EPI-13 EPI-36	120 VAC	1.9-130VAC, 2.4-130VDC	MKT-106	AMI-101A	POT-102	XMA-106	XMA-105	repeat cycle timer function
	220 VAC	1.9-130VAC, 2.4-130VDC	MKT-106	AMI-101C	POT-102	XMA-106	XMA-105	repeat cycle timer function
	12 VDC							
	24 VDC							
EPI-51 EPI-91 EPI-151	120 VAC	1.9-130VAC, 2.4-130VDC	MKT-106	AMI-101A	POT-102	XMA-106	XMA-105	repeat cycle timer function
	220 VAC	1.9-130VAC, 2.4-130VDC	MKT-106	AMI-101C	POT-102	XMA-106	XMA-105	repeat cycle timer function

* Feedback potentiometer is only required when using a Feedback Transmitter.

Actuator Model	Power Source	Mounting Kit	Feedback Pot	*Feedback Transmitter		*Power Supply
				0-5V / 0-10V	4-20mA	
EPI-Lite	120 VAC	MKT-143	POT-102	XMA-106	XMA-105	
EPI-3	120 VAC	MKT-110	POT-102	XMA-106	XMA-105	
	220 VAC	MKT-110	POT-102	XMA-106	XMA-105	
	12 VDC	MKT-110	POT-102	**	XMA-105	
	24 VDC	MKT-110	POT-102	**	XMA-105	
EPI-6 EPI-13 EPI-36	120 VAC	MKT-106	POT-102	XMA-106	XMA-105	PWR-102
	220 VAC	MKT-106	POT-102	XMA-106	XMA-105	PWR-102A
	12 VDC	MKT-106	POT-102	**	XMA-105	
	24 VDC	MKT-106	POT-102	**	XMA-105	
EPI-51 EPI-91 EPI-151	120 VAC	MKT-106	POT-102	XMA-106	XMA-105	PWR-102
	220 VAC	MKT-106	POT-102	XMA-106	XMA-105	PWR-102A

* PWR-102/PWR-102A power supply is not required if transmitter is externally powered.

** Call factory for more information.

Actuator Model	Mounting Kit	Feedback Pot	
		1K ohms	5K ohms
EPI-Lite	MKT-143	POT-102	POT-111
EPI-3	MKT-110	POT-102	POT-111
EPI-6 EPI-13 EPI-36 EPI-51	MKT-134	POT-102	POT-111
EPI-91 EPI-151	MKT-133	POT-102	POT-111