



▲ PEAKTRONICS


Feedback Signal and Command Signal Products




**XMA-105
XMA-106**




XMA-107




POT-101



**XMA-104A
XMA-108**




MLT-100A



CLI-100B

**PWR-102
PWR-102A**



Feedback Signal Transmitters

The **XMA-105/106** transmitters are ideal for providing a 2-wire feedback signal when used with Peaktronics actuator controllers - the AMC, AMI, LRC, SVC, and DMC Series controllers provide power for the transmitter. For feedback only applications, the **XMA-107** is a 2-wire loop powered transmitter.

Model	Description	List
XMA-105	Feedback Potentiometer Transmitter, 4-20mA	\$ Call
XMA-106	Feedback Potentiometer Transmitter, 0-5V/0-10V	\$ Call
XMA-107	Feedback Potentiometer Transmitter, 4-20mA loop powered	\$ Call

Command Signal Products

Model	Description	List
POT-101	Command Potentiometer, 1K ohm (terminates with screw terminals; includes 0-100% dial plate and knob)	\$ Call
XMA-104A	Command Potentiometer Transmitter, 4-20mA loop powered (for use with 100 ohm to 10K ohm potentiometers)	\$ Call
MLT-100A	Manual Loop Transmitter, 4-20mA loop powered (includes XMA-104A, bracket, 1K ohm 1 turn potentiometer, 0-100% dial plate, and knob)	\$ Call
XMA-108	Slide Wire Transmitter, 4-20mA loop powered (for use with 100 ohm to 10K ohm slide wires)	\$ Call

Displays and Power Supplies

Model	Description	List
CLI-100B	Current Loop Indicator, 4-20mA loop powered (includes bezel and hardware to panel mount)	\$ Call
PWR-102	24VDC / 60mA Power Supply, 117VAC (fits on most MKT Series mounting kits and powers XMA-105 or XMA-106 transmitters)	\$ Call
PWR-102A	24VDC / 60mA Power Supply, 234VAC (fits on most MKT Series mounting kits and powers XMA-105 or XMA-106 transmitters)	\$ Call