

<b>HKC</b>  <i>(See General Notes and Footnotes on Page 20)</i>		<b>AC DIGITAL POSITIONERS</b>						<b>DC DIGITAL POSITIONERS</b>			
		<b>STANDARD</b>						<b>STANDARD</b>			
		<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-108) Modbus (Modbus Feedback Signal only)						<b>Command Signal</b> 4-20mA / 0-10V / 2-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-108) Modbus (Modbus Feedback Signal only)			
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> mA VDC	<b>Feedback Signal</b> mA VDC Aux Close Aux Open Fault Relays	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated Aux Close Aux Open Fault Relays	<b>Feedback Signal</b> Modbus	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated Aux Close Aux Open Fault Relays	<b>Feedback Signal</b> Modbus
		<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
HQ-006	24VDC	_____	_____	_____	_____	_____	_____	DHC-400 MKT-145 POT-102 EXE-100 2/EEF-100 (2)	DHC-400 MKT-145 POT-102 EXE-100 2/EEF-100 OTX-101 (2)	DHC-400 MKT-145 POT-102 EXE-100 2/EEF-100 OTR-101 (2)	DHC-400 MKT-145 POT-102 EXE-100 2/EEF-100 OCM-102 (2)
	110VAC	DHC-100 MKT-145 POT-102 EXE-100 2/EEF-100 (2)	DHC-100 MKT-145 POT-102 EXE-100 2/EEF-100 OTX-100 (2)	DHC-100 MKT-145 POT-102 EXE-100 2/EEF-100 OTR-100 (2)	DHC-100 MKT-145 POT-102 EXE-100 2/EEF-100 OTX-101 (2)	DHC-100 MKT-145 POT-102 EXE-100 2/EEF-100 OTR-101 (2)	DHC-100 MKT-145 POT-102 EXE-100 2/EEF-100 OCM-102 (2)	_____	_____	_____	_____
	220VAC	DHC-100A MKT-145 POT-102 EXE-100 2/EEF-100 (2)	DHC-100A MKT-145 POT-102 EXE-100 2/EEF-100 OTX-100 (2)	DHC-100A MKT-145 POT-102 EXE-100 2/EEF-100 OTR-100 (2)	DHC-100A MKT-145 POT-102 EXE-100 2/EEF-100 OTX-101 (2)	DHC-100A MKT-145 POT-102 EXE-100 2/EEF-100 OTR-101 (2)	DHC-100A MKT-145 POT-102 EXE-100 2/EEF-100 OCM-102 (2)	_____	_____	_____	_____

<b>HKC</b>  <i>(See General Notes and Footnotes on Page 20)</i>		<b>AC ANALOG POSITIONERS</b>											
		<b>STANDARD</b>						<b>MINIATURE</b>					
		<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V			<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V with Repeat Cycle Timer			<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V			<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V with Repeat Cycle Timer		
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V
		<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
HQ-006	24VDC	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____
	110VAC	AMC-100A MKT-145 POT-102 EXE-100 2/EEF-100 (2)	AMC-100A MKT-145 POT-102 EXE-100 2/EEF-100 XMA-105 (2)	AMC-100A MKT-145 POT-102 EXE-100 2/EEF-100 XMA-106 (2)	N/A	N/A	N/A	AMC-103 MKT-145 POT-102 EXE-100 2/EEF-100 (2)	AMC-103 MKT-145 POT-102 EXE-100 2/EEF-100 XMA-105 (2)	AMC-103 MKT-145 POT-102 EXE-100 2/EEF-100 XMA-106 (2)	N/A	N/A	N/A
	220VAC	AMC-100C MKT-145 POT-102 EXE-100 2/EEF-100 (2)	AMC-100C MKT-145 POT-102 EXE-100 2/EEF-100 XMA-105 (2)	AMC-100C MKT-145 POT-102 EXE-100 2/EEF-100 XMA-106 (2)	N/A	N/A	N/A	AMC-103A MKT-145 POT-102 EXE-100 2/EEF-100 (2)	AMC-103A MKT-145 POT-102 EXE-100 2/EEF-100 XMA-105 (2)	AMC-103A MKT-145 POT-102 EXE-100 2/EEF-100 XMA-106 (2)	N/A	N/A	N/A

<b>HKC</b>  <i>(See General Notes and Footnotes on Page 20)</i>		<b>AC LOG RATE POSITIONERS</b>			<b>DC ANALOG POSITIONERS</b>					
		<b>STANDARD</b>			<b>STANDARD</b>				<b>MINIATURE</b>	
		<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-104A)			<b>Command Signal</b> 4-20mA / 0-10V / 2-10V / 0-5V / 1-5V includes selectable Log Rate function 0-135 ohm Slide Wire (add XMA-104A)				<b>Command Signal</b> 4-20mA Only	
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>without Current Trip</b>		<b>with Current Trip</b>		<b>without Current Trip</b>	
					<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA
		<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
HQ-006	24VDC				DMC-102 MKT-145 POT-102 EXE-100 2/EEF-100 (2)	DMC-102 MKT-145 POT-102 EXE-100 2/EEF-100 XMA-105 (2)	DMC-102A MKT-145 POT-102 EXE-100 2/EEF-100 (2)	DMC-102A MKT-145 POT-102 EXE-100 2/EEF-100 XMA-105 (2)	DMC-101 MKT-145 POT-102 EXE-100 2/EEF-100 (2) (5)	DMC-101 MKT-145 POT-102 EXE-100 2/EEF-100 XMA-105 (2) (5)
	110VAC	LRC-101A,G MKT-145 POT-102 EXE-100 2/EEF-100 (2)	LRC-101A,G MKT-145 POT-102 EXE-100 2/EEF-100 XMA-105 (2)	LRC-101A,G MKT-145 POT-102 EXE-100 2/EEF-100 XMA-106 (2)	_____	_____	_____	_____	_____	_____
	220VAC	LRC-101B,H MKT-145 POT-102 EXE-100 2/EEF-100 (2)	LRC-101B,H MKT-145 POT-102 EXE-100 2/EEF-100 XMA-105 (2)	LRC-101B,H MKT-145 POT-102 EXE-100 2/EEF-100 XMA-106 (2)	_____	_____	_____	_____	_____	_____

<b>HKC</b> <i>(See General Notes and Footnotes on Page 20)</i>		<b>ON/OFF APPLICATIONS</b>					<b>TIMER ONLY APPLICATIONS</b>			
		<b>STANDARD</b>					<b>AC or DC Motor Converter Module</b>	<b>AC Repeat Cycle Timers</b>	<b>MINIATURE</b>	
		<b>Control Signal</b> 1.9-130VAC 2.4-130VDC with Repeat Cycle Timer			<b>Control Signal</b> Switch Relay Open Collector with Adjustable Current Trip				<b>AC Sequence Timers</b>	<b>DC Sequence Timers</b>
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 1-5mA	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
HQ-006	24VDC	_____	_____	_____	RCM-101A EXE-100 2/EEF-100 (2) (5)	RCM-101C MKT-145 POT-102 EXE-100 2/EEF-100 (2) (5)	_____	_____	_____	DST-100A EXE-100 2/EEF-100 (2) (5)
	110VAC	AMI-103 EXE-100 2/EEF-100 (2)	AMI-103 MKT-145 POT-102 EXE-100 2/EEF-100 (2)	AMI-103 MKT-145 POT-102 EXE-100 2/EEF-100 (2)	_____	_____	_____	N/A	AST-100 EXE-100 2/EEF-100 (2)	_____
	220VAC	AMI-103A EXE-100 2/EEF-100 (2)	AMI-103A MKT-145 POT-102 EXE-100 2/EEF-100 (2)	AMI-103A MKT-145 POT-102 EXE-100 2/EEF-100 (2)	_____	_____	_____	N/A	AST-100A EXE-100 2/EEF-100 (2)	_____

<b>HKC</b> (See General Notes and Footnotes on Page 20)		<b>FEEDBACK SIGNAL ONLY APPLICATIONS</b>					
		<b>1K Ohm Feedback Pot Only</b>	<b>4-20mA Feedback (2-wire)</b>	<b>4-20mA Feedback (3-wire)</b>	<b>4-20mA Feedback Powered</b>	<b>0-5V 0-10V Feedback (3-wire)</b>	<b>0-5V 0-10V Feedback Powered</b>
<b>Actuator Model</b>	<b>Power Source</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
<b>HQ-006</b>	24VDC	MKT-145 POT-102	_____	_____	_____	_____	_____
	110VAC	MKT-145 POT-102	_____	_____	MKT-145 POT-102 XMA-105 PWR-102 EXE-100 2/EEF-100 (2)	_____	MKT-145 POT-102 XMA-106 PWR-102 EXE-100 2/EEF-100 (2)
	220VAC	MKT-145 POT-102	_____	_____	MKT-145 POT-102 XMA-105 PWR-102A EXE-100 2/EEF-100 (2)	_____	MKT-145 POT-102 XMA-106 PWR-102A EXE-100 2/EEF-100 (2)

<b>HKC</b>  (See General Notes and Footnotes on Page 20)		<b>AC DIGITAL POSITIONERS</b>						<b>DC DIGITAL POSITIONERS</b>				
		<b>STANDARD</b>						<b>STANDARD</b>				
		<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-108) Modbus (Modbus Feedback Signal only)						<b>Command Signal</b> 4-20mA / 0-10V / 2-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-108) Modbus (Modbus Feedback Signal only)				
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> mA VDC	<b>Feedback Signal</b> mA VDC Aux Close Aux Open Fault Relays	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated Aux Close Aux Open Fault Relays	<b>Feedback Signal</b> Modbus	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated Aux Close Aux Open Fault Relays	<b>Feedback Signal</b> Modbus
		<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
HQ-008 HQ-010	24VDC	_____	_____	_____	_____	_____	_____	_____	DHC-400 MKT-141 POT-102 EXE-100 2/EEF-101 (4)	DHC-400 MKT-141 POT-102 EXE-100 2/EEF-101 OTX-101 (4)	DHC-400 MKT-141 POT-102 EXE-100 2/EEF-101 OTR-101 (4)	DHC-400 MKT-141 POT-102 EXE-100 2/EEF-101 OCM-102 (4)
	24VAC (order 24VDC Motor)	DHC-100B ADM-100 MKT-141 POT-102 EXE-100 2/EEF-101 (4)	DHC-100B ADM-100 MKT-141 POT-102 EXE-100 2/EEF-101 OTX-100 (4)	DHC-100B ADM-100 MKT-141 POT-102 EXE-100 2/EEF-101 OTR-100 (4)	DHC-100B ADM-100 MKT-141 POT-102 EXE-100 2/EEF-101 OTX-101 (4)	DHC-100B ADM-100 MKT-141 POT-102 EXE-100 2/EEF-101 OTR-101 (4)	DHC-100B ADM-100 MKT-141 POT-102 EXE-100 2/EEF-101 OCM-102 (4)	_____	_____	_____	_____	
	110VAC	DHC-100 MKT-141 POT-102 EXE-100 2/EEF-101 (4)	DHC-100 MKT-141 POT-102 EXE-100 2/EEF-101 OTX-100 (4)	DHC-100 MKT-141 POT-102 EXE-100 2/EEF-101 OTR-100 (4)	DHC-100 MKT-141 POT-102 EXE-100 2/EEF-101 OTX-101 (4)	DHC-100A MKT-141 POT-102 EXE-100 2/EEF-101 OTR-101 (4)	DHC-100 MKT-141 POT-102 EXE-100 2/EEF-101 OCM-102 (4)	_____	_____	_____	_____	
	220VAC	DHC-100A MKT-141 POT-102 EXE-100 2/EEF-101 (4)	DHC-100A MKT-141 POT-102 EXE-100 2/EEF-101 OTX-100 (4)	DHC-100A MKT-141 POT-102 EXE-100 2/EEF-101 OTR-100 (4)	DHC-100A MKT-141 POT-102 EXE-100 2/EEF-101 OTX-101 (4)	DHC-100A MKT-141 POT-102 EXE-100 2/EEF-101 OTR-101 (4)	DHC-100A MKT-141 POT-102 EXE-100 2/EEF-101 OCM-102 (4)	_____	_____	_____	_____	

<b>HKC</b>  (See General Notes and Footnotes on Page 20)		<b>AC ANALOG POSITIONERS</b>											
		<b>STANDARD</b>						<b>MINIATURE</b>					
		<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V			<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V with Repeat Cycle Timer			<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V			<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V with Repeat Cycle Timer		
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V
		<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
HQ-008 HQ-010	24VDC	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____
	24VAC (order 24VDC Motor)	AMC-101E ADM-100 MKT-141 POT-102 EXE-100 2/EEF-101 (4)	AMC-101E ADM-100 MKT-141 POT-102 EXE-100 2/EEF-101 XMA-105 (4)	AMC-101E ADM-100 MKT-141 POT-102 EXE-100 2/EEF-101 XMA-106 (4)	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
	110VAC	AMC-100A MKT-141 POT-102 EXE-100 2/EEF-101 (4)	AMC-100A MKT-141 POT-102 EXE-100 2/EEF-101 XMA-105 (4)	AMC-100A MKT-141 POT-102 EXE-100 2/EEF-101 XMA-106 (4)	N/A	N/A	N/A	AMC-103 MKT-141 POT-102 (4)	AMC-103 MKT-141 POT-102 XMA-105 (4)	AMC-103 MKT-141 POT-102 XMA-106 (4)	N/A	N/A	N/A
	220VAC	AMC-100C MKT-141 POT-102 EXE-100 2/EEF-101 (4)	AMC-100C MKT-141 POT-102 EXE-100 2/EEF-101 XMA-105 (4)	AMC-100C MKT-141 POT-102 EXE-100 2/EEF-101 XMA-106 (4)	N/A	N/A	N/A	AMC-103A MKT-141 POT-102 (4)	AMC-103A MKT-141 POT-102 XMA-105 (4)	AMC-103A MKT-141 POT-102 XMA-106 (4)	N/A	N/A	N/A

<b>HKC</b>  <i>(See General Notes and Footnotes on Page 20)</i>		<b>AC LOG RATE POSITIONERS</b>			<b>DC ANALOG POSITIONERS</b>					
		<b>STANDARD</b>			<b>STANDARD</b>				<b>MINIATURE</b>	
		<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-104A)			<b>Command Signal</b> 4-20mA / 0-10V / 2-10V / 0-5V / 1-5V includes selectable Log Rate function 0-135 ohm Slide Wire (add XMA-104A)				<b>Command Signal</b> 4-20mA Only	
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>without Current Trip</b>		<b>with Current Trip</b>		<b>without Current Trip</b>	
					<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA
		<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
HQ-008 HQ-010	24VDC	_____	_____	_____	DMC-102 MKT-141 POT-102 EXE-100 2/EEF-101 (4)	DMC-102 MKT-141 POT-102 EXE-100 2/EEF-101 XMA-105 (4)	DMC-102A MKT-141 POT-102 EXE-100 2/EEF-101 (4)	DMC-102A MKT-141 POT-102 EXE-100 2/EEF-101 XMA-105 (4)	DMC-101 MKT-141 POT-102 (4)	DMC-101 MKT-141 POT-102 XMA-105 (4)
	24VAC (order 24VDC Motor)	LRC-101C,I ADM-100 MKT-141 POT-102 EXE-100 2/EEF-101 (4)	LRC-101C,I ADM-100 MKT-141 POT-102 EXE-100 2/EEF-101 XMA-105 (4)	LRC-101C,I ADM-100 MKT-141 POT-102 EXE-100 2/EEF-101 XMA-106 (4)	_____	_____	_____	_____	_____	_____
	110VAC	LRC-101A,G MKT-141 POT-102 EXE-100 2/EEF-101 (4)	LRC-101A,G MKT-141 POT-102 EXE-100 2/EEF-101 XMA-105 (4)	LRC-101A,G MKT-141 POT-102 EXE-100 2/EEF-101 XMA-106 (4)	_____	_____	_____	_____	_____	_____
	220VAC	LRC-101B,H MKT-141 POT-102 EXE-100 2/EEF-101 (4)	LRC-101B,H MKT-141 POT-102 EXE-100 2/EEF-101 XMA-105 (4)	LRC-101B,H MKT-141 POT-102 EXE-100 2/EEF-101 XMA-106 (4)	_____	_____	_____	_____	_____	_____



<b>HKC</b> <i>(See General Notes and Footnotes on Page 20)</i>		<b>ON/OFF APPLICATIONS</b>					<b>TIMER ONLY APPLICATIONS</b>			
		<b>STANDARD</b>					<b>AC or DC Motor Converter Module</b>	<b>AC Repeat Cycle Timers</b>	<b>MINIATURE</b>	
		<b>Control Signal</b> 1.9-130VAC 2.4-130VDC with Repeat Cycle Timer			<b>Control Signal</b> Switch Relay Open Collector with Adjustable Current Trip				<b>AC Sequence Timers</b>	<b>DC Sequence Timers</b>
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 1-5mA	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
HQ-008 HQ-010	24VDC	_____	_____	_____	RCM-101A EXE-100 2/EEF-101	RCM-101C MKT-141 POT-102 EXE-100 2/EEF-101 (4)	ADM-100	_____	_____	DST-100A MKT-141A
	24VAC (order 24VDC Motor)	AMI-103B ADM-100 EXE-100 2/EEF-101	AMI-103B ADM-100 MKT-141 POT-102 EXE-100 2/EEF-101 XMA-105 (4)	AMI-103B ADM-100 MKT-141 POT-102 EXE-100 2/EEF-101 XMA-106 (4)	_____	_____	ADM-100	N/A	N/A	_____
	110VAC	AMI-103 EXE-100 2/EEF-101	AMI-103 MKT-141 POT-102 EXE-100 2/EEF-101 XMA-105 (4)	AMI-103 MKT-141 POT-102 EXE-100 2/EEF-101 XMA-106 (4)	_____	_____	_____	N/A	AST-100 MKT-141A	_____
	220VAC	AMI-103A EXE-100 2/EEF-101	AMI-103A MKT-141 POT-102 EXE-100 2/EEF-101 XMA-105 (4)	AMI-103A MKT-141 POT-102 EXE-100 2/EEF-101 XMA-106 (4)	_____	_____	_____	N/A	AST-100A MKT-141A	_____

<b>HKC</b> (See General Notes and Footnotes on Page 20)		<b>FEEDBACK SIGNAL ONLY APPLICATIONS</b>					
		<b>1K Ohm Feedback Pot Only</b>	<b>4-20mA Feedback (2-wire)</b>	<b>4-20mA Feedback (3-wire)</b>	<b>4-20mA Feedback Powered</b>	<b>0-5V 0-10V Feedback (3-wire)</b>	<b>0-5V 0-10V Feedback Powered</b>
<b>Actuator Model</b>	<b>Power Source</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
<b>HQ-008 HQ-010</b>	24VDC	MKT-141 POT-102 (4)	MKT-141 POT-102 XMA-107 (4)	MKT-141 POT-102 XMA-105 (4)	_____	MKT-141 POT-102 XMA-106 (4)	_____
	24VAC (order 24VDC Motor)	ADM-100 MKT-141 POT-102 (4)	ADM-100 MKT-141 POT-102 XMA-107 (4)	ADM-100 MKT-141 POT-102 XMA-105 (4)	N/A	ADM-100 MKT-141 POT-102 XMA-106 (4)	N/A
	110VAC	MKT-141 POT-102 (4)	MKT-141 POT-102 XMA-107 (4)	MKT-141 POT-102 XMA-105 (4)	MKT-141 POT-102 XMA-105 PWR-102 EXE-100 2/EEF-101 (4)	MKT-141 POT-102 XMA-106 (4)	MKT-141 POT-102 XMA-106 PWR-102 EXE-100 2/EEF-101 (4)
	220VAC	MKT-141 POT-102 (4)	MKT-141 POT-102 XMA-107 (4)	MKT-141 POT-102 XMA-105 (4)	MKT-141 POT-102 XMA-105 PWR-102A EXE-100 2/EEF-101 (4)	MKT-141 POT-102 XMA-106 (4)	MKT-141 POT-102 XMA-106 PWR-102A EXE-100 2/EEF-101 (4)

<b>HKC</b> <i>(See General Notes and Footnotes on Page 20)</i>		<b>AC DIGITAL POSITIONERS</b>						<b>DC DIGITAL POSITIONERS</b>			
		<b>STANDARD</b>						<b>STANDARD</b>			
		<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-108) Modbus (Modbus Feedback Signal only)						<b>Command Signal</b> 4-20mA / 0-10V / 2-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-108) Modbus (Modbus Feedback Signal only)			
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> mA VDC	<b>Feedback Signal</b> mA VDC Aux Close Aux Open Fault Relays	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated Aux Close Aux Open Fault Relays	<b>Feedback Signal</b> Modbus	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated Aux Close Aux Open Fault Relays	<b>Feedback Signal</b> Modbus
		<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
HQ-015 HQ-020 HQ-030	24VDC	_____	_____	_____	_____	_____	_____	DHC-400 MKT-137 POT-102 (3)	DHC-400 MKT-137 POT-102 OTX-101 (3)	DHC-400 MKT-137 POT-102 OTR-101 (3)	DHC-400 MKT-137 POT-102 OCM-102 (3)
	24VAC (order 24VDC Motor)	DHC-100B ADM-100 MKT-137 POT-102 (3)	DHC-100B ADM-100 MKT-137 POT-102 OTX-100 (3)	DHC-100B ADM-100 MKT-137 POT-102 OTR-100 (3)	DHC-100B ADM-100 MKT-137 POT-102 OTX-101 (3)	DHC-100B ADM-100 MKT-137 POT-102 OTR-101 (3)	DHC-100B ADM-100 MKT-137 POT-102 OCM-102 (3)	_____	_____	_____	_____
	110VAC	DHC-100 MKT-137 POT-102 (3)	DHC-100 MKT-137 POT-102 OTX-100 (3)	DHC-100 MKT-137 POT-102 OTR-100 (3)	DHC-100 MKT-137 POT-102 OTX-101 (3)	DHC-100 MKT-137 POT-102 OTR-101 (3)	DHC-100 MKT-137 POT-102 OCM-102 (3)	_____	_____	_____	_____
	220VAC	DHC-100A MKT-137 POT-102 (3)	DHC-100A MKT-137 POT-102 OTX-100 (3)	DHC-100A MKT-137 POT-102 OTR-100 (3)	DHC-100A MKT-137 POT-102 OTX-101 (3)	DHC-100A MKT-137 POT-102 OTR-101 (3)	DHC-100A MKT-137 POT-102 OCM-102 (3)	_____	_____	_____	_____

<b>HKC</b> <i>(See General Notes and Footnotes on Page 20)</i>		<b>AC ANALOG POSITIONERS</b>											
		<b>STANDARD</b>						<b>MINIATURE</b>					
		<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V			<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V with Repeat Cycle Timer			<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V			<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V with Repeat Cycle Timer		
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V
		<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
HQ-015 HQ-020 HQ-030	24VDC	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____	_____
	24VAC (order 24VDC Motor)	_____	AMC-101E ADM-100 MKT-137 POT-102 XMA-105	AMC-101E ADM-100 MKT-137 POT-102 XMA-106	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
	110VAC	_____	AMC-100A MKT-137 POT-102 XMA-105	AMC-100A MKT-137 POT-102 XMA-106	AMC-100A MKT-137 POT-102 RCT-100	AMC-100A MKT-137 POT-102 RCT-100 XMA-105	AMC-100A MKT-137 POT-102 RCT-100 XMA-106	AMC-103 MKT-137 POT-102	AMC-103 MKT-137 POT-102 XMA-105	AMC-103 MKT-137 POT-102 XMA-106	AMC-103 MKT-137 POT-102 RCT-100	AMC-103 MKT-137 POT-102 RCT-100 XMA-105	AMC-103 MKT-137 POT-102 RCT-100 XMA-106
	220VAC	_____	AMC-100C MKT-137 POT-102 XMA-105	AMC-100C MKT-137 POT-102 XMA-106	AMC-100C MKT-137 POT-102 RCT-100A	AMC-100C MKT-137 POT-102 RCT-100A XMA-105	AMC-100C MKT-137 POT-102 RCT-100A XMA-106	AMC-103A MKT-137 POT-102	AMC-103A MKT-137 POT-102 XMA-105	AMC-103A MKT-137 POT-102 XMA-106	AMC-103A MKT-137 POT-102 RCT-100A	AMC-103A MKT-137 POT-102 RCT-100A XMA-105	AMC-103A MKT-137 POT-102 RCT-100A XMA-106

<b>HKC</b>  <i>(See General Notes and Footnotes on Page 20)</i>		<b>AC LOG RATE POSITIONERS</b>			<b>DC ANALOG POSITIONERS</b>					
		<b>STANDARD</b>			<b>STANDARD</b>				<b>MINIATURE</b>	
		<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-104A)			<b>Command Signal</b> 4-20mA / 0-10V / 2-10V / 0-5V / 1-5V includes selectable Log Rate function 0-135 ohm Slide Wire (add XMA-104A)				<b>Command Signal</b> 4-20mA Only	
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>without Current Trip</b>		<b>with Current Trip</b>		<b>without Current Trip</b>	
					<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA
		<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
	24VDC	_____	_____	_____	DMC-102 MKT-137 POT-102	DMC-102 MKT-137 POT-102 XMA-105	DMC-102A MKT-137 POT-102	DMC-102A MKT-137 POT-102 XMA-105	N/A	N/A
HQ-015 HQ-020 HQ-030	24VAC (order 24VDC Motor)	LRC-101C,I ADM-100 MKT-137 POT-102	LRC-101C,I ADM-100 MKT-137 POT-102 XMA-105	LRC-101C,I ADM-100 MKT-137 POT-102 XMA-106	_____	_____	_____	_____	_____	_____
	110VAC	LRC-101A,G MKT-137 POT-102	LRC-101A,G MKT-137 POT-102 XMA-105	LRC-101A,G MKT-137 POT-102 XMA-106	_____	_____	_____	_____	_____	_____
	220VAC	LRC-101B,H MKT-137 POT-102	LRC-101B,H MKT-137 POT-102 XMA-105	LRC-101B,H MKT-137 POT-102 XMA-106	_____	_____	_____	_____	_____	_____

<b>HKC</b> <i>(See General Notes and Footnotes on Page 20)</i>		<b>ON/OFF APPLICATIONS</b>					<b>TIMER ONLY APPLICATIONS</b>			
		<b>STANDARD</b>					<b>AC or DC Motor Converter Module</b>	<b>AC Repeat Cycle Timers</b>	<b>MINIATURE</b>	
		<b>Control Signal</b> 1.9-130VAC 2.4-130VDC with Repeat Cycle Timer			<b>Control Signal</b> Switch Relay Open Collector with Adjustable Current Trip				<b>AC Sequence Timers</b>	<b>DC Sequence Timers</b>
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 1-5mA	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
	24VDC	_____	_____	_____	RCM-101D MKT-137A SLR-100	N/A	ADM-100	_____	_____	N/A
HQ-015 HQ-020 HQ-030	24VAC (order 24VDC Motor)	AMI-103B ADM-100 MKT-137A	AMI-103B ADM-100 MKT-137 POT-102 XMA-105	AMI-103B ADM-100 MKT-137 POT-102 XMA-106	_____	_____	ADM-100	ADM-100 MTB-103 RCT-100B	N/A	_____
	110VAC	AMI-103 MKT-137A	AMI-103 MKT-137 POT-102 XMA-105	AMI-103 MKT-137 POT-102 XMA-106	_____	_____	_____	MTB-103 RCT-100	AST-100 MKT-137A	_____
	220VAC	AMI-103A MKT-137A	AMI-103A MKT-137 POT-102 XMA-105	AMI-103A MKT-137 POT-102 XMA-106	_____	_____	_____	MTB-103 RCT-100A	AST-100A MKT-137A	_____

<b>HKC</b> (See General Notes and Footnotes on Page 20)		<b>FEEDBACK SIGNAL ONLY APPLICATIONS</b>					
		<b>1K Ohm Feedback Pot Only</b>	<b>4-20mA Feedback (2-wire)</b>	<b>4-20mA Feedback (3-wire)</b>	<b>4-20mA Feedback Powered</b>	<b>0-5V 0-10V Feedback (3-wire)</b>	<b>0-5V 0-10V Feedback Powered</b>
		<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
<b>Actuator Model</b>	<b>Power Source</b>						
HQ-015 HQ-020 HQ-030	24VDC	MKT-175 POT-102	MKT-175 POT-102 XMA-107	MKT-175 POT-102 XMA-105	_____	MKT-175 POT-102 XMA-106	_____
	24VAC (order 24VDC Motor)	ADM-100 MKT-137 POT-102	ADM-100 MKT-137 POT-102 XMA-107	ADM-100 MKT-137 POT-102 XMA-105	N/A	ADM-100 MKT-137 POT-102 XMA-106	N/A
	110VAC	MKT-175 POT-102	MKT-175 POT-102 XMA-107	MKT-175 POT-102 XMA-105	MKT-137 POT-102 XMA-105 PWR-102	MKT-175 POT-102 XMA-106	MKT-137 POT-102 XMA-106 PWR-102
	220VAC	MKT-175 POT-102	MKT-175 POT-102 XMA-107	MKT-175 POT-102 XMA-105	MKT-137 POT-102 XMA-105 PWR-102A	MKT-175 POT-102 XMA-106	MKT-137 POT-102 XMA-106 PWR-102A

<b>HKC</b> <i>(See General Notes and Footnotes on Page 20)</i>		<b>AC DIGITAL POSITIONERS</b>						<b>DC DIGITAL POSITIONERS</b>				
		<b>STANDARD</b>						<b>STANDARD</b>				
		<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-108) Modbus (Modbus Feedback Signal only)						<b>Command Signal</b> 4-20mA / 0-10V / 2-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-108) Modbus (Modbus Feedback Signal only)				
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> mA VDC	<b>Feedback Signal</b> mA VDC Aux Close Aux Open Fault Relays	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated Aux Close Aux Open Fault Relays	<b>Feedback Signal</b> Modbus	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated	<b>Feedback Signal</b> 4-20mA (2-wire) Isolated Aux Close Aux Open Fault Relays	<b>Feedback Signal</b> Modbus
		<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
HQ-050 HQ-060 HQ-080 HQ-120 HQ-200 HQ-300	110VAC	DHC-100 MKT-137 POT-102 (3)	DHC-100 MKT-137 POT-102 OTX-100 (3)	DHC-100 MKT-137 POT-102 OTR-100 (3)	DHC-100 MKT-137 POT-102 OTX-101 (3)	DHC-100 MKT-137 POT-102 OTR-101 (3)	DHC-100 MKT-137 POT-102 OCM-102 (3)	_____	_____	_____	_____	
	220VAC	DHC-100A MKT-137 POT-102 (3)	DHC-100A MKT-137 POT-102 OTX-100 (3)	DHC-100A MKT-137 POT-102 OTR-100 (3)	DHC-100A MKT-137 POT-102 OTX-101 (3)	DHC-100A MKT-137 POT-102 OTR-101 (3)	DHC-100A MKT-137 POT-102 OCM-102 (3)	_____	_____	_____	_____	



<b>HKC</b>  (See General Notes and Footnotes on Page 20)		<b>AC ANALOG POSITIONERS</b>											
		<b>STANDARD</b>						<b>MINIATURE</b>					
		<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V			<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V with Repeat Cycle Timer			<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V			<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V with Repeat Cycle Timer		
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V
		<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
HQ-050 HQ-060 HQ-080 HQ-120 HQ-200 HQ-300	110VAC	_____	AMC-101A MKT-137 POT-102 XMA-105	AMC-101A MKT-137 POT-102 XMA-106	AMC-101A MKT-137 POT-102 RCT-100	AMC-101A MKT-137 POT-102 RCT-100 XMA-105	AMC-101A MKT-137 POT-102 RCT-100 XMA-106	N/A	N/A	N/A	N/A	N/A	N/A
	220VAC	_____	AMC-101C MKT-137 POT-102 XMA-105	AMC-101C MKT-137 POT-102 XMA-106	AMC-101C MKT-137 POT-102 RCT-100A	AMC-101C MKT-137 POT-102 RCT-100A XMA-105	AMC-101C MKT-137 POT-102 RCT-100A XMA-106	N/A	N/A	N/A	N/A	N/A	N/A

<b>HKC</b> <i>(See General Notes and Footnotes on Page 20)</i>		<b>AC LOG RATE POSITIONERS</b>			<b>DC ANALOG POSITIONERS</b>					
		<b>STANDARD</b>			<b>STANDARD</b>				<b>MINIATURE</b>	
		<b>Command Signal</b> 4-20mA / 0-10V / 0-5V / 1-5V 0-135 ohm Slide Wire (add XMA-104A)			<b>Command Signal</b> 4-20mA / 0-10V / 2-10V / 0-5V / 1-5V includes selectable Log Rate function 0-135 ohm Slide Wire (add XMA-104A)				<b>Command Signal</b> 4-20mA Only	
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>without Current Trip</b>		<b>with Current Trip</b>		<b>without Current Trip</b>	
					<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA
		<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
HQ-050 HQ-060 HQ-080 HQ-120 HQ-200 HQ-300	110VAC	LRC-101A,G MKT-137 POT-102	LRC-101A,G MKT-137 POT-102 XMA-105	LRC-101A,G MKT-137 POT-102 XMA-106	_____	_____	_____	_____	_____	_____
	220VAC	LRC-101B,H MKT-137 POT-102	LRC-101B,H MKT-137 POT-102 XMA-105	LRC-101B,H MKT-137 POT-102 XMA-106	_____	_____	_____	_____	_____	_____

<b>HKC</b> <i>(See General Notes and Footnotes on Page 20)</i>		<b>ON/OFF APPLICATIONS</b>					<b>TIMER ONLY APPLICATIONS</b>			
		<b>STANDARD</b>					<b>AC or DC Motor Converter Module</b>	<b>AC Repeat Cycle Timers</b>	<b>MINIATURE</b>	
		<b>Control Signal</b> 1.9-130VAC 2.4-130VDC with Repeat Cycle Timer			<b>Control Signal</b> Switch Relay Open Collector with Adjustable Current Trip				<b>AC Sequence Timers</b>	<b>DC Sequence Timers</b>
<b>Actuator Model</b>	<b>Power Source</b>	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 4-20mA	<b>Feedback Signal</b> 0-5V 0-10V	<b>Feedback Signal</b> None	<b>Feedback Signal</b> 1-5mA	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>	<b>Order Parts</b>
HQ-050 HQ-060 HQ-080 HQ-120 HQ-200 HQ-300	110VAC	AMI-103 MKT-137A	AMI-103 MKT-137 POT-102 XMA-105	AMI-103 MKT-137 POT-102 XMA-106	_____	_____	_____	MTB-103 RCT-100	N/A	_____
	220VAC	AMI-103A MKT-137A	AMI-103A MKT-137 POT-102 XMA-105	AMI-103A MKT-137 POT-102 XMA-106	_____	_____	_____	MTB-103 RCT-100A	N/A	_____

<b>HKC</b> (See General Notes and Footnotes on Page 20)		<b>FEEDBACK SIGNAL ONLY APPLICATIONS</b>					
		1K Ohm Feedback Pot Only	4-20mA Feedback (2-wire)	4-20mA Feedback (3-wire)	4-20mA Feedback Powered	0-5V 0-10V Feedback (3-wire)	0-5V 0-10V Feedback Powered
		Order Parts	Order Parts	Order Parts	Order Parts	Order Parts	Order Parts
Actuator Model	Power Source						
HQ-050 HQ-060 HQ-080 HQ-120 HQ-200 HQ-300	110VAC	MKT-175 POT-102	MKT-175 POT-102 XMA-107	MKT-175 POT-102 XMA-105	MKT-137 POT-102 XMA-105 PWR-102	MKT-175 POT-102 XMA-106	MKT-137 POT-102 XMA-106 PWR-102
	220VAC	MKT-175 POT-102	MKT-175 POT-102 XMA-107	MKT-175 POT-102 XMA-105	MKT-137 POT-102 XMA-105 PWR-102A	MKT-175 POT-102 XMA-106	MKT-137 POT-102 XMA-106 PWR-102A

**GENERAL NOTES**

- A) The following mounting kits allow the addition of (2) auxiliary switches: MKT-137, MKT-137A, MKT-141, MKT-141A, MKT-145, and MKT-179.
- B) The EXE-100 Nema 4 enclosure requires miscellaneous wires and drilling of mounting and conduit holes to meet customer requirements.
- C) Replace DHC-100A with DHC-100D for CE certification (see CE Declaration of Conformity 1001-6A).

**FOOTNOTES**

- (1) XMA-104A must be mounted external to actuator.
- (2) Actuator must be ordered with 1/2" NPT conduit entrances or use a 13.5PG to 1/2" NPT thread adapter.
- (3) Replace MKT-137 with MKT-176 for extra high-resolution control.
- (4) Replace MKT-141 with MKT-179 for 180 degree applications.
- (5) Actuator's mechanical override feature is not operational with this application.